MICROH DJ

www.microhdj.com

USER MANUAL

LED NEO SCAN 30TS

Keep this manual for future reference.

1. INTRODUCTION AND UNPACKING

Thank you for purchasing the MICROH NEO SCAN 30TS moving head fixture. For your own safety and knowledge, please read this manual before installing or operating the device. This manual covers the important information on installation and applications. Please install and operate the fixture according to instructions. Meanwhile, please keep this manual for future reference.

The MICROH NEO SCAN 30TS model is a moving head light with the latest advancements in smart, efficient product design. Combined with the advanced technology of today's stage lighting products, advanced control technology and is very user-friendly; this unit fully complies with CE standards.

The MICROH NEO SCAN 30TS has a 30W LED SPOT uses advanced design and processing technology, with the appearance of high-strength heat resistant engineering plastic made with the modern streamlined design, to make it look neat and beautiful. This product contains a white LED light source, eight motors, two gobo wheels, a color wheel, you can change out many kinds of patterns. This fixture is perfect for use in television, banquet and convention centres, nightclubs, large-scale performances and other professional venues. Please carefully unpack the fixture when you receive it and check to see if it was damaged during the transportation. Please check whether the following items are included inside the box:

Fixture – One **Power Cord** – One **User Manual** – One **DMX Cable** – One

2. SAFTEY INSTRUCTIONS

This device has been delivered in safe working condition. In order to maintain this condition and to ensure safe operation, it is absolutely necessary for the user to follow the safety instructions and warning notes written in this user manual.

If the device has been exposed to temperature changes, do not switch it on immediately. The arising condensation could damage the device. Leave the device switched off until it has reached room temperature, and is dry.

This device falls under protection-class I, therefore it is essential that the device be grounded. The electrical connection must be carried out by a qualified technician.

The device should only be used with rated voltage and frequency. Make sure that the available voltage is not higher than 120V as stated at the end of this manual.

Make sure the power cord is never crimped or damaged in any way, as this could cause shock and damage. If your power cord is damaged in any way, please purchase a new cable from your local MICROH dealer. Always disconnect power, when the device is not in use or before cleaning it. Never pull out the plug by tugging the power cord.

During initial start-up, some smoke or smell may arise. This is a normal process, and does not necessarily mean that the device is defective. It should decrease gradually. Please do not project the beam onto combustible substances.

Fixtures cannot be installed on or near combustible substances. Keep more than 3m distance from wall for proper ventilation and air flow. If your fixture is or has become damaged in any way, it shall be exclusively replaced or repaired by the manufacturer to avoid any hazard.


CAUTION!
Never touch the device during operation!
The housing may heat up
CAUTION!
Never look directly into the light source,
as sensitive persons may suffer an epileptic shock.
CAUTION!
The electric connection must only be carried out by a qualified electrician.

3. MOUNTING AND INSTALLATION

Caution: For added protection, mount the fixtures in areas outside walking paths, seating areas, or in areas were the fixture might be reached by unauthorized personnel. Before mounting the fixture to any surface, make sure that the installation area can hold a minimum point load of 10 times the device's weight. Fixture installation must always be secured with a secondary safety attachment, such as an appropriate safety cable. Never stand directly below the device when mounting, removing, or servicing the fixture.

Whether installing inverted on a truss, ceiling or set on a flat level surface (see illustration below). Be sure this fixture is kept at least 3m (3.3 ft.) away from any flammable materials (decoration etc.). Always use and install the supplied safety cable as a safety measure to prevent accidental damage and/or injury in the event the clamp fails.

Mounting Points: Overhead mounting requires extensive experience, including calculating working load limits. A knowledge of the installation material being used and periodic safety inspection of all installation material and the fixture are all imperative and should only be performed by a qualified technician. Improper installation can result in bodily injury and damage. Be sure to complete all rigging and installation procedures before connecting the main power cord to the appropriate wall outlet.

Clamp Mounting: The MICROH NEO SCAN 30TS provides a unique mounting bracket assembly that integrates a single bracket to be used to mount on a truss or the floor. When mounting this fixture to truss, be sure to secure an appropriately rated clamp to the included bracket fitted through the center hole. As an added safety measure, be sure to attach at least one properly rated safety cable to the fixture.

Regardless of the rigging option you choose for your MICROH NEO SCAN 30TS, always be sure to secure your fixture with a safety cable. The fixture provides a built-in rigging point for a safety cable on the hanging bracket as illustrated above. Be sure to only use the designated rigging point for the safety cable and never secure a safety cable to a carrying handle.

4. DMX-512 CONTROL CONNECTIONS

This fixture complies with international USITT DMX standards and can be used with either a 3 pin or 5 pin DMX connector. Plug in the provided 3 pin XLR cable to the female 3-pin XLR output of your controller and the other side to the male 3-pin XLR input of the MICROH NEO SCAN 30TS. To connect the units to DMX, you must daisy chain the fixtures together as referred in the diagram below. Always end your DMX-512 connection with a DMX terminator.



For installations where the DMX cable has to run a long distance, or is in an electrically noisy environment, it is recommended to use a DMX terminator. This helps in preventing corruption of the digital control signal by electrical noise. The DMX terminator is simply an XLR plug with a 120 Ω resistor connected between pins 2 and 3,which is then plugged into the output XLR socket of the last fixture in the chain. Please see illustrations below.



5. SETUP MENU



6. DMX CHANNEL

8 CHANNEL DMX

CHANNEL	FUNCTION	DESCRIPTION	VALUE
CH1	PAN	PAN	000-255
CH2	TILT	TILT	000-255
CH3	COLOURS	WHITE	000-014
		RED	015-029
		BLUE	030-044
		YELLOW	045-059
		ORANGE	060-074
		PINK	075-089
		LIGHT BLUE	090-104
		GREEN	105-119
		LIGHT YELLOW	120-127
		COLOUR WHEEL SCROLL SLOW TO FAST	128-255

CH4	GOBOS	OPEN	000-006
		GOBO 1	007-013
		GOBO 2	014-020
		GOBO 3	021-027
		GOBO 4	028-034
		GOBO 5	035-041
		GOBO 6	042-048
		GOBO 7	049-055
		GOBO 8	056-063
		OPEN SHAKE	064-070
		GOBO 1 SHAKE	071-077
		GOBO 2 SHAKE	078-084
		GOBO 3 SHAKE	085-091
		GOBO 4 SHAKE	092-098
		GOBO 5 SHAKE	099-105
		GOBO 6 SHAKE	106-112
		GOBO 7 SHAKE	113-119
		GOBO 8 SHAKE	120-127
		GOBO WHEEL ROTATION SLOW TO FAST	128-255
CH5	SHUTTER	BLACKOUT	000-007
		SHUTTER OPEN	008-015
		STROBE SLOW TO FAST	016-131
		SHUTTER OPEN	132-139
		SHUTTER OPEN SLOW, CLOSE FAST	140-180
		SHUTTER OPEN	181-189
		SHUTTER OPEN FAST, CLOSE SLOW	190-231
		REST AFTER 3-5 SECONDS	232-239
		RANDOM STROBE	240-247
		SHUTTER OPEN	248-255
CH6	DIMMER	INTENSITY 0 - 100%	000-255
CH7	MACROS	NO FUNCTION	000-007
		MACRO 1	008-025
		MACRO 2	026-043
		MACRO 3	044-061
		MACRO 4	062-079
		MACRO 5	080-097
		MACRO 6	098-115
		MACRO 7	116-133
		MACRO 8	134-151
		MACRO 9	152-169
		MACRO 10	170-187
		MACRO 11	188-205
		MACRO 12	206-223
		MACRO 13	224-241
		MACRO 14	242-255
CH8	MACRO SPEED	SLOW TO FAST	000-255

8. MAINTENANCE AND CLEANING

The following points have to be considered during the inspection:

1) All screws for installing the device or parts of the device must be tightly connected, and must not be corroded.

2) There must not be any deformations on the housing, colour lenses, fixations or installation spots (ceiling, suspension, trussing).

3) Mechanically moved parts must not show any traces of wearing and must not rotate with unbalances.

4) The electric power supply cables must not show any damage, material fatigue or sediments.

Further instructions depending on the installation spot and usage must be handled by a skilled installer or technician. Any safety issues must be resolved.

In order to keep the fixture in good condition and extend the life, we suggest regular cleaning to the fixture.

1) Clean the inside and outside lens each week to avoid the light output from darkening due to accumulation of dust, dirt, etc.

2) Clean the fan each week.

3) A detailed electrical check by approved technician every three months is advised. Ensure the circuit contacts are in good condition.

We recommend a frequent cleaning of the device. Please use a moist, lint- free cloth. Never use alcohol or solvents.
There are no serviceable parts inside the device. Please refer to the instructions under “Installation instructions”.
Should you need any spare parts, please order genuine MICROH parts from your local dealer.

IF YOU SHOULD EXPERIENCE ANY PROBLEMS OR ISSUES PLEASE CONTACT MICROH PROFESSIONAL PRODUCTS BY EMAIL AT info@microhdj.com

In the event that your unit is defective in any way, please contact your local dealer to obtain an RA number for service repair.

DISCLAIMER – MICROH believes that the information contained within this user manual is accurate. However, MICROH is not responsible for any error or addendums to this manual. If you have any comments or general suggestions on how this manual can be improved please contact info@microhdj.com. Thank you.

Notes:

MICROH DJ

www.microhdj.com